

# EMERGENCY PROCEDURES

PLACE THIS POSTER IN A PROMINENT POSITION

## IN THE EVENT OF FIRE CALL 999

1. Shut all valves on tank or cylinders and emergency control outside the building by turning clockwise.
2. Call Fire Brigade and refer to presence of L.P. Gas Tank
3. Keep tank cool by waterspray, if possible
4. Ring the Calor Gas Emergency Service number **0845 7 444 999**

## GAS LEAKAGE CALL 0845 7 444 999

1. Extinguish all sources of ignition
2. Shut all valves on tank or cylinders and emergency control outside the building by turning clockwise.
3. Ring Calor Gas Emergency Service Number – **0845 7 444 999**
4. Do not operate electrical switches
5. Open all doors and windows. Ventilate at low level (LPG is heavier than air)

## GAS FAILURE CALL 0845 7 444 999

1. Check contents indicator and pressure gauge on tank if fitted
2. Turn off tap at each appliance
3. Shut all valves on tank or cylinders and emergency control outside the building by turning clockwise
4. Ring the Calor Gas Emergency Service – **0845 7 444 999**

Show location of emergency control valve

**CALOR**